

CEILINGS

# USG MIDDLE EAST CEILING PANEL MAINTENANCE GUIDE

**USG ME**   
INNOVATIVE SOLUTIONS. EVERYTIME.

# CEILING PANEL MAINTENANCE GUIDE

Choosing the best ceiling for your project can make all the difference. When maintenance is necessary, certain procedures should be followed to protect the appearance and high performance of acoustical panels.

## CELEBRETTO METAL CEILING SOLUTIONS

PRODUCTS	CLEANING AND MAINTENANCE
Hook-On Corridor System - Hook On Island Hook On Intersecto Linear Track Torsion Spring Strip Ceiling Paraline Metal Baffles Crossing Baffles Quadra Cell Metal Canopies Expanded Metal Mesh ceilings Snap-In (Hinge Down) Geometrix Lay-In Metal Ceiling Clip-In Metal Ceiling	Panel can be cleaned easily with microfiber feather dust brush or vacuum to remove the visible dust. Use clean cloth and mild detergent and little water. Remove any obvious dirt before applying liquid cleaner. After cleaning each tile with the solution, the tile should be quickly dried with a dry and clean cloth before moving to the next tile. Do not clean with a damp sponge, and do not use acetate ammonia or highly concentrated chlorine, bromide or other harsh chemicals.

## ACOUSTICAL DRYWALL CEILING

PRODUCTS	CLEANING AND MAINTENANCE
Ensemble™ Monosilent Skyrock Ecoblock - R6 Skyrock Ecoblock - R12 Skyrock Ecoblock - R8-15-20 Skyrock Ecoblock - Q9 Skyrock Ecoblock - Q12	General cleaning of dust and loose dirt may be easily achieved using a soft brush or vacuum cleaner. Panels can be cleaned with an art gum eraser or dampened cloth or sponge containing as little water as possible. Panels should never be soaked or immersed in water. Cleaning can also be carried out by specialist contractors using proprietary methods and chemicals. It is strongly recommended that a trial area be cleaned to ensure that there is no detrimental effect on the ceiling panel.

## SOFT FIBER PANEL LAMINATED WITH FACTORY APPLIED PAINTED FIBERGLASS SCRIM

PRODUCTS	CLEANING AND MAINTENANCE
Halcyon™ Canopies Tranquille Halcyon™ Louna™ Elite Louna™ Natural Louna™ Hi CAC	Panel can be cleaned easily with a soft brush or vacuum. To clean panel, use a clean, white cloth with warm water or a mild detergent and wipe panel surface. Do not use acetate ammonia or highly concentrated chlorine, bromide or other harsh chemicals.

## SOFT FIBER PANEL LAMINATED WITH PREPAINTED FIBERGLASS SCRIM

PRODUCTS	CLEANING AND MAINTENANCE
Halcyon™ Black Louna™ Baffle Louna™ Elegant Louna™ Hi CAC Black	Panel can be cleaned easily with a soft brush or vacuum. To clean panel, use HEPA vacuum filter to minimize air borne dust during the cleaning process. Care must be taken while vacuuming to avoid excessive pressure. Use a blotting action to minimize potential damage of surface texture on ceiling and wall panels.

## CEILING PANEL MAINTENANCE GUIDE

### WOOD WOOL PANEL FINISHED WITH FACTORY APPLIED FINISH PAINT

PRODUCTS	CLEANING AND MAINTENANCE
Skyneest Wood Wool Baffles	Panel can be cleaned easily with a soft brush or vacuum. Do not use liquid cleaning solution as it may harm the wood wool fiber. Care must be taken while vacuuming to avoid excessive pressure. Use a blotting action to minimize potential damage of surface texture on ceiling panels. Use HEPA vacuum filter to minimize airborne dust during the cleaning process.
Skyneest Wood Wool Canopies	
Skyneest Wood Wool Exposed Grid	
Skyneest Wood Wool Ceiling Direct Mounting	

### MINERAL FIBER PANEL FINISHED WITH FACTORY-APPLIED WATER-BASED PAINT

PRODUCTS	CLEANING AND MAINTENANCE
Athena Cross Fissured Auratone Designer Series Favia Favia Acoustic Olympia™ Olympia Micro™ Omni Radar™ Skylite Acoustic Taiga Taiga Perforated	Clean with a soft brush or vacuum gently. Any dusting concerns for Mineral Fiber panels caused by punched perforations can be resolved by using a microfiber feather dust brush. Be certain to clean the mineral fiber panels in one direction only. This will prevent rubbing dust into the surface of the ceiling panel. May be cleaned with a moist cloth or a sponge dampened in water containing mild soap. The cloth or sponge should contain as little soapy water solution as possible. After washing panel face, any moisture remaining should be wiped off with a dry cloth.

### MINERAL FIBER PANEL LAMINATED WITH FIBERGLASS MEMBRANE AND FINISHED WITH FACTORY-APPLIED LATEX PAINT

PRODUCTS	CLEANING AND MAINTENANCE
Sonata	Panel can be cleaned easily with a soft brush or vacuum. To clean panel, use a clean, white cloth with warm water or a mild detergent and wipe panel surface.

### MINERAL FIBER PANEL LAMINATED WITH EMBOSSED VINYL-FACED MEMBRANE

PRODUCTS	CLEANING AND MAINTENANCE
Sparta	Clean with a damp sponge, mild detergent and water. Do not use acetate ammonia or highly concentrated chlorine, bromide or other harsh chemicals. May be cleaned with a moist cloth or a sponge dampened in water containing mild soap. The cloth or sponge should contain as little soapy water solution as possible. After washing panel face, any moisture remaining should be wiped off with a dry cloth.

### CERAMIC BONDED MINERAL FIBER PANEL FINISHED WITH FACTORY-APPLIED WATER-BASED PAINT

PRODUCTS	CLEANING AND MAINTENANCE
Radar™ Ceramic	Radar™ Ceramic panels are less affected by moisture and will withstand repeated washings with mild detergents or germicidal cleaners. Clean with a soft brush or vacuum gently. Any dusting concerns for Ceramic Bonded Mineral Fiber panels caused by punched perforations can be resolved by using a microfiber feather dust brush.

## USG MIDDLE EAST CEILING PANEL MAINTENANCE GUIDE

### CAST MINERAL FIBER WITH FACTORY APPLIED FINISH PAINT

PRODUCTS	CLEANING AND MAINTENANCE
Glacier™	Clean with a soft brush or vacuum gently. Any dusting concerns for Cast Mineral Fiber panels caused by punched perforations can be resolved by using a microfiber feather dust brush.
Sandrift™	Care must be taken while vacuuming to avoid excessive pressure. Use a blotting action to minimize potential damage of surface texture on ceiling panels.

### GYPSUM CEILING PANEL FINISHED WITH FACTORY-APPLIED WATER-BASED PAINT

PRODUCTS	CLEANING AND MAINTENANCE
Painted Soundblock - R6 Soundblock - R8-15-20 Soundblock - Q3 Soundblock - Q9 Soundblock - Q12	Clean with a damp sponge, mild detergent and water. Do not use acetate ammonia or highly concentrated chlorine, bromide or other harsh chemicals.

### GYPSUM CEILING PANEL LAMINATED WITH EMBOSSED VINYL-FACED MEMBRANE

PRODUCTS	CLEANING AND MAINTENANCE
Shades Soundblock -R6 Soundblock - R8-15-20 Soundblock - Q3 Soundblock - Q9 Soundblock - Q12	Clean with a damp sponge, mild detergent and water. Do not use acetate ammonia or highly concentrated chlorine, bromide or other harsh chemicals. May be cleaned with a moist cloth or a sponge dampened in water containing mild soap. The cloth or sponge should contain as little soapy water solution as possible. After washing panel face, any moisture remaining should be wiped off with a dry cloth.

### HEALTHCARE CEILINGS

PRODUCTS	CLEANING AND MAINTENANCE
Clean Room™ Skylite Clean Taiga Hygiene Halcyon™ Healthcare Sonata Healthcare Louna™ Hygiene	Remove any obvious dirt before applying liquid cleaner. Panel can be disinfected by lightly spraying the surface and wiping with a clean white cloth. Acceptable colorless disinfectants include Hydrogen peroxide, Isopropyl alcohol, quaternary ammonium or sodium hypochlorite. Do not mix cleaning solutions and follow the cleaner manufacturer's instructions. Do not use acetate ammonia or highly concentrated chlorine, bromide or other harsh chemicals. Always follow the EPA's and CDC's latest Release Guidance for Cleaning and Disinfecting ceilings panels for healthcare applications.

### SUSPENDED CEILING SYSTEM

PRODUCTS	CLEANING AND MAINTENANCE
DONN® Brand Acoustical Suspension System Quadra Safe Ceiling Carrier	Remove panel material and perform any necessary cleaning maintenance with non-solvent based commercial cleaner. Immediately remove any corrosive substances or chemicals that would harm painted finishes (i.e. wallpaper adhesives). Clean with a damp sponge, mild detergent and water. Do not use acetate ammonia or highly concentrated chlorine, bromide or other harsh chemicals.

### PAINTING AND RETOUCHING

#### PANELS:

Ceiling panels may be touched-up by spraying a thinned, non-bridging vinyl-acrylic flat wall paint. However, USG ME cannot be responsible for the finished appearance or performance for the field-painted ceiling's panels. USG ME cannot guarantee that the published surface burning characteristics, fire resistance ratings, acoustical performance, dimensional stability, sag, or light reflectance performance will remain the same after repainting.

All warranties will be voided by field painting. When painting acoustical materials, the painter should be very careful not to close up the perforations or fissures in the material. It is through these openings in the surface that sound waves enter the body of the acoustical material and are absorbed. Care should be taken that these perforations are not clogged. Spray painting will result in a more uniform coating on embossed or irregular surfaces.

Field painting of vinyl-faced products is not recommended.

Please consult the USG ME Technical Department for expert advice and recommendations.

#### GRIDS AND SUSPENSIONS:

Touch up all minor scratches and spots, as acceptable, or replace damaged sections when touch-up is not permitted. Repainting of suspension member shall be with a high-quality solvent base enamel paint and applied as recommended by paint manufacturer.

### DISCLAIMER

- Cleaning conditions and aesthetics may be impacted by additional site conditions. These instructions pertain only to the maintenance of the aesthetics and integrity of USG Middle East ceiling systems. Please consult the manufacturer's instructions and guidance regarding any cleaning product or disinfectant product for use and efficacy.
- It is recommended that only clear cleaners be used, as dyed liquids can permanently discolor the finish of the ceiling tiles.
- Cleaning is only recommended for the finished face of the board.
- The panels should never be soaked in water or other liquids, as this can have an adverse effect on board integrity.
- Use the safety recommendations for gloves and eye protection that are given by the manufacturer of the cleaner and cleaning equipment.



**SEE US ON LINKEDIN**  
/usgme



**FIND US ON FACEBOOK**  
/usgme



**FOLLOW US ON INSTAGRAM**  
/usg\_me



**FOLLOW US ON TWITTER**  
/usg\_me



**SEE US ON YOUTUBE**  
/USG Middle East



**MESSAGE US ON WHATSAPP**  
/+966 92 003 5672

**FACTORY OF USG MIDDLE EAST LTD. CO.**

7410 (Wasil), Street #23, Cross 76  
2nd Industrial City, Dammam 34326-4201  
Kingdom of Saudi Arabia

**CUSTOMER SERVICE**

t +966 13 812 0995  
f +966 13 812 1029  
info@usgme.com  
www.usgme.com

**WEBSITE**

[www.usgme.com](http://www.usgme.com)



**WHATSAPP**

+966 92 003 5672



**USG ME**   
INNOVATIVE SOLUTIONS. EVERYTIME.